

	Gautam Solar Private Limited	Document No.	GSPL/IQC/WI/002
		Issue Date	01-12-2024
	Document Title: Quality(IQC)	Rev. No./Date	00
	Type of Document: WI For Anodizing Thickness Of Aluminium Frame	Page	Page 1 of 6

1. Purpose: To Determine the Anodizing Thickness of Frame During Incoming Quality Inspection.
2. Scope: For Inspection of Frame used in GSPL.
3. Reference Documents: NA
4. Authority and Responsibility: IQC And Inprocess Quality Control Engineer
5. Procedure: As below

Rules for Operating Personnel		
<div>1. Never use a machine if you are not trained or not Familiar with it.</div> <div>2. Never Remove Shield or Machine Guard.</div> <div>3. Wear Proper PPE as Per Requirement.</div> <div>4. Check the Safety device on a regular, Periodic basic to confirm that they are operating correctly.</div> <div>5. Keep hand and Body clear when Operating Machine, Always Maintain a safe distance from Moving Parts.</div> <div>6. Never try to climb or extent your hand over safety device, Equipment and Guards.</div>		
Work Instructions (Steps)	Pictures	Check Points

Prepared By:	Approved By:	Documents Status
<div>Quality Team</div>	<div>Quality Head</div>	

- 1) Switch on the instrument (Fig.1).
- 2) Place the instrument (Anodizing meter) on specimen (object to be tested- e.g Al.frame). The measurement reading appears in display (Fig.2).
- 3) Lift up instrument at least 25 mm from the surface. Place the instrument down again for the next measurement. Measure the Anodizing thickness at 10 different positions on same frame.
- 4) Before testing, calibrate the Anodizing thickness gauge (or Coating thickness gauge).
- 5) Incase anodize thickness less than



Fig.1



Fig.2

- 1). Always wear the personal protective equipment.

Prepared By:

Approved By:

Documents Status

Quality Team

Quality Head

	Gautam Solar Private Limited	Document No.	GSPL/IQC/WI/002
		Issue Date	01-12-2024
	Document Title: Quality(IQC)	Rev. No./Date	00
	Type of Document: WI For Anodizing Thickness Of Aluminium Frame	Page	Page 3 of 6

15micron then do double sampling for again verification.

6) Incase in double sampling it will fail again then inform to purchase/supplier for action plan and material will put on HOLD with proper identification.

Calibration Process :-

Prepared By:	Approved By:	Documents Status
<u>Quality Team</u>	<u>Quality Head</u>	

- 1) Perform 5 to 10 measurement on the uncoated reference part (Fig.3.1, Fig.3.2).
- 2) Press the multifunctional key ok to complete the normalization. The message “please measure several times: CAL-rated value or please measure several times : 75.3 μ m appears in the display.”
- 3) Place the calibration foil on the uncoated reference part (Fig.4).
- 4) Perform 5 to 10 measurement on the calibration foil. To do this place the probe on the foil within the circle each time (Fig.5).
- 5) Press the multifunctional key Ok to quit the measurement and to



Fig.3.1



Fig.3.2

Prepared By:

Approved By:

Documents Status

Quality Team

Quality Head

- set up the CAL rated value.
- Use the multifunctional key $\uparrow\downarrow$ to set the rated value of the calibration foil.The rated value printed on calibration foil.
 - Remove calibration foil from the reference part.
 - Press multifunctionl key Ok to complete the calibration.



Fig.4



Fig.5

Check for Potential Hazards signage on WorkPlace

	Machine Grounding
---	-------------------

Prepared By:	Approved By:	Documents Status
<div>Quality Team</div>	<div>Quality Head</div>	

